## **NOISE ABATEMENT PROCEDURES**

### **MACKAY**

## 1. PREFERRED RUNWAYS

1.1 LANDING RWY 32 1.2 TAKE-OFF RWY 14

#### 2. PREFERRED FLIGHT PATHS

## 2.1 - Arriving Aircraft

(a) Landing RWY 32:

From the SOUTH - make a straight-in approach or overfly for a LEFT base.

From the WEST, NORTH - track for a LEFT base.

and NORTH-EAST

(b) Landing RWY 14:

From the NORTH and - make a straight-in approach or NORTH-EAST - wake a straight-in approach or overfly for a RIGHT base.

From the SOUTH and WEST

 track for a RIGHT base, or track for a LEFT base seaward of the coast until NORTH of the Pioneer River

ID

# 2.2 - Departing Aircraft

(a) Departing RWY 32:

To the WEST or SOUTH - turn LEFT.

To the NORTH or - no restrictions.

NORTH-EAST

D

(b) Departing RWY 14:

All departing aircraft are to turn RIGHT or continue straight ahead, except that LEFT turns are permitted, provided aircraft keep seaward of the coast until NORTH of the Pioneer River.

### 3. TRAINING FLIGHTS

See AIP/ERSA.

