

2.2.3 Military Strike/Fighter Aircraft:

NOTE: These procedures are additional to and take precedence over the requirements contained in Darwin SID "DARWIN.....DEPARTURE - ALL RUNWAYS".

Rolling take-offs are preferred. Aircraft are to minimise use of afterburner. VTOL OPS not permitted.

RWY 11:

High Level Sorties shall maintain runway heading until above 5000FT AMSL, then turn.

Low Level Sorties (below 5000FT) if approved by RAAF Darwin ABCP due to operational requirements shall maintain runway heading until LAPAR/10TAC/9DME (GNSS), then turn and remain outside 10TAC/9DME(GNSS) to intercept outbound track.

RWY 29:

Aircraft shall maintain runway heading until above 2000FT AMSL and established over water, then turn.

3 - TRAINING

See AIP/ERSA.

4 - NOTE:

Australian registered jet propelled aircraft that are noise certified as per ICAO Annex 16 may conduct operations using Runway 18/36.