

## ARRIVAL: **TEBOT TWO ALPHA**

## RWY 01L:

10 NM MSA 2600

- From TEBOT track 234° to URBIN
- Turn LEFT, track 179° to ANIRI Cross ANIRI BTN 9000ft AND FL120
- Turn RIGHT, track 195° to DOMBO Cross DOMBO BTN 5000ft and 9000ft
- Turn RIGHT, track 234° to VEVEX Cross VEVEX AT or BLW 7000ft
- Turn RIGHT, track 243° to COTON Cross COTON AT or ABV 4000ft
- Track 243° to NIXEL
- MAX IAS 230KT AT NIXEL
- Turn RIGHT, track 286° to VANTI Turn RIGHT, track 334° to TANIK for ILS, RNP Z or LOC RWY 01L approach

MAX IAS 185KT AT TANİK

## **RWY 19R:**

- From TEBOT track 234° to URBIN
- Turn RIGHT, track 257° to DOLSU Cross DOLSU BTN 8000ft and 9000ft

RNP 1

- Track 257° to PILIG Cross PILIG BTN 5000ft and 6000ft MAX IAS 230KT AT PILIG
- Turn LEFT, track 219° to LAVIN Cross LAVIN AT or ABV 4000ft
- Turn LEFT, track 196° to OSOKO for ILS, RNP Z or LOC RWY 19R approach MAX IAS 185KT AT OSOKO

## **COMMUNICATIONS FAILURE: PROCEDURE IN IMC** IF ABLE CTC BN ATC ON TEL: (07) 3866-3694

Squawk 7600, comply with vertical navigation requirements, but not below MSA.

230KT

Track via the latest STAR clearance to the nominated runway, then fly the most suitable approach in accordance with ERSA EMERG Section 1.5.

BBNSR29-182 Changes: MSA.

