

**NOISE ABATEMENT PROCEDURES
SYDNEY (KINGSFORD-SMITH)****1. PREFERRED RUNWAYS****1.1 - (a) 2300-0600 HR local time** (applicable to all aircraft):

LANDING - Runway 34L

TAKE-OFF - Runway 16R

**(b) DAILY MON-SAT 0600-0700 HR local time and
SUN 0600-0800 HR local time**

LANDING & TAKE-OFF:

1. Runway 16L for Take-Off and Runway 34L for Landing
2. Runway 16L and 16R for Take-Off and Runway 34L for Landing
3. EQUAL - Runway 25 for Take-Off and Runway 34L and 34R for Landing
Runway 16L and 16R for Take-Off and Runway 25 for Landing
Runway 16L and 16R for Take-Off and Runway 07 for Landing
4. EQUAL - Runway 16L and 16R
Runway 34L and 34R
5. EQUAL - Runway 07 or 25

**(c) DAILY MON - FRI 0700 - 2245 HR local time and
SAT 0700-2200 HR local time and
SUN 0800-2200 HR local time**

LANDING and TAKE - OFF:

1. Runway 16L for Take-Off and Runway 34L for Landing
2. EQUAL-Runway 16L and 16R for Take-Off and Runway 07 for Landing
Runway 25 for Take-Off and Runway 34L and 34R for Landing
Runway 16L and 16R for Take-Off and Runway 25 for Landing
3. EQUAL-Runway 16L and 16R
Runway 34L and 34R
4. EQUAL-Runway 07 or 25

(d) SAT and SUN 2200-2245 HR local time

LANDING and TAKE-OFF:

1. Runway 16L for Take-Off and Runway 34L for Landing
2. Runway 16L and 16R for Take-off and Runway 34L for Landing
3. Runway 16L and 16R for Take-off and Runway 25 for Landing
4. Runway 16L and 16R for Take-off and Runway 07 for Landing
5. Runway 25 for Take-off and Runway 34L and 34R for Landing
6. EQUAL-Runway 16L and 16R
Runway 34L and 34R
7. EQUAL-Runway 07 or 25

(e) 2245-2300 HR local time

LANDING and TAKE-OFF:

1. Runway 16L for Take-Off and Runway 34L for Landing
2. Runway 16L and 16R for Take-off and Runway 34L for Landing
3. EQUAL-Runway 16L and 16R for Take-off and Runway 25 for Landing
Runway 16L and 16R for Take-off and Runway 07 for Landing
4. Runway 16L and 16R

- 1.2 Jet noise abatement climb procedures apply for the following runways:
Runway 16R 2300-0600 HR local time
Runways 34L & 34R at other times.