

## NOISE ABATEMENT PROCEDURES

### BRISBANE

Air Traffic Control will maximise the use of preferred flight paths and over water operations. pilots and Air Traffic Control will determine when operational requirements preclude the use of noise abatement procedures.

#### 1. PREFERRED RUNWAYS OPERATIONS

Preferred RWY operations will be nominated during normal operations.  
Air Traffic control may nominate alternative runway configurations:

- a. when required due to operational requirements or
- b. due unusual operations such as emergencies or
- c. to achieve the best possible noise abatement outcome, this includes Simultaneous Opposite Direction Parallel Runway Operations (SODPROPS) outside of nominated priority times if conditions suit.
  - i) Daily MON-FRI 0600-2100 Local and  
SAT 0800-1200 Local and  
SUN 1600-2100 Local

| PRIORITY | LAND    | TAKE-OFF |
|----------|---------|----------|
| 1.       | 19L/19R | 19L/19R  |
| 2.       | 01L/01R | 01L/01R  |

- ii) Daily SUN-FRI 2100-2200 Local and  
SAT 0600-0800 Local and  
SAT 1200 Local – SUN 1600 Local

| PRIORITY                                                                 | LAND    | TAKE-OFF |
|--------------------------------------------------------------------------|---------|----------|
| 1. Simultaneous Opposite Direction Parallel Runway Operations (SODPROPS) | 19R     | 01R      |
| 2.                                                                       | 19L/19R | 19L/19R  |
| 3.                                                                       | 01L/01R | 01L/01R  |

- iii) 2200-0600 Local (applicable to all aircraft):

| PRIORITY                                                                                                     | LAND | TAKE-OFF |
|--------------------------------------------------------------------------------------------------------------|------|----------|
| 1. Simultaneous Opposite Direction Parallel Runway Operations (SODPROPS) /Reciprocal Runway Operations (RRO) | 19R  | 01R      |
| 2. (RRO)                                                                                                     | 19L  | 01R      |
| 3.                                                                                                           | 19R  | 19L      |
| 4.                                                                                                           | 19L  | 19L      |
| 5.                                                                                                           | 01R  | 01L/01R  |

From 2200-0600 Local, RWY 01L arrivals and RWY 19R departures only available in emergency, loss of infrastructure or extreme weather conditions. Brisbane Airport Corporation (BAC) approval required for all other operations.  
TEL: H24 07 3406 3171 or 0412 052 977.