

# Guide to our operations

2024





Artwork from Luke Duffy

We acknowledge and embrace a culture that celebrates diversity, inclusion, and equality for all. In making this statement we acknowledge Aboriginal and Torres Strait Islander peoples as the Traditional Owners and Custodians of the country on which we live and work, now called Australia.

Information contained within this document is accurate as of the date of publication. Details, figures and other information may have changed.  
© Copyright Airservices Australia 2024

# Contents

05

Introduction  
Our governance  
Our purpose

06

Who's responsible for what?

08

Our operations at a glance

10

Air traffic control  
Types of air traffic controllers  
Who's in control

11

How airspace works

16

Australian airspace architecture

20

Our technology

22

Aircraft noise

23

Weather

24

Accidents and emergencies

26

Unusual activity



# Introduction

Airservices is Australia's air navigation and aviation fire fighting service provider. We provide air traffic control and aviation rescue fire fighting services at designated airports around the country.

Each year we manage domestic and international air traffic operations for more than 150 million passenger movements across almost 4 million aircraft arrivals and departures in a region covering 11 per cent of the world's airspace.

The safety and integrity of Australia's air navigation ecosystem is our primary consideration.

Even to the most seasoned traveller, the world of air traffic control remains largely a mystery. This guide has been produced to demystify air traffic control for the broader public and to provide valuable insights.

## Our governance

Airservices is wholly owned by the Australian Government and governed by a Board of Directors appointed by the Minister for Infrastructure, Transport, Regional Development and Local Government. Our services are funded through revenue from our customers.

## Our purpose

Our purpose is to provide safe, secure, efficient and environmentally responsible services that are valued by the aviation industry and community. We are positioned to be the industry partner for keeping skies safe and for delivering distinctive value to our customers.

As air traffic continues to grow, Airservices is committed to delivering safe and efficient services to all who use Australia's changing skies.

## Contact us

You can find more information on our services at [airservicesaustralia.com](https://airservicesaustralia.com) or by phoning 1300 301 120.

You can also follow Airservices on X, LinkedIn and YouTube.

# Who's responsible for what?

A number of Government departments, agencies and organisations have responsibilities across the aviation industry.

Airservices provides air traffic control and aviation rescue fire fighting services to the aviation industry, as well as maintaining technology used by the industry for navigation and surveillance.

The Australian Maritime Safety Authority is responsible for search and rescue coordination, which is conducted from the Joint Rescue Coordination Centre in Canberra.


The Australian Transport Safety Bureau is Australia's national transport safety investigator. When things go wrong in transport safety, the Australian Transport Safety Bureau undertakes an investigation to determine what happened.

The Bureau of Meteorology is Australia's national weather agency. Through Airservices, it provides aviation users with meteorological information necessary for safe and efficient operations, including the provision of observations, forecasts, warnings and advisories.

The Civil Aviation Safety Authority (CASA) is Australia's safety regulator for civil air operations and the operation of Australian aircraft overseas. It is the agency responsible for licensing of pilots and air traffic controllers, certification of aircraft and aircraft operators. Through the Office of Airspace Regulation, it also has responsibility for airspace regulation.

The Department of Defence is responsible for military aviation operations and air traffic control at airports with a shared civil and military use. Airservices is also working closely with Defence to deliver a single harmonised civil-military air traffic management system (OneSKY Australia™).

The Department of Infrastructure, Transport, Regional Development, Communications, and the Arts oversees government legislation and policy relating to airports and aviation, including curfews, noise insulation programs and aircraft noise regulations.



# Our operations at a glance



## Air traffic control

We have two major operating centres in Melbourne and Brisbane and a corporate office in Canberra. We operate 29 air traffic control towers at international and regional airports, providing air navigation services across 11 per cent of the world's airspace.

Our towers are located at Adelaide, Albury, Alice Springs, Archerfield, Avalon, Bankstown, Brisbane, Broome, Cairns, Camden, Canberra, Coffs Harbour, Essendon, Gold Coast, Hamilton Island, Hobart, Jandakot, Karratha, Launceston, Mackay, Melbourne, Moorabbin, Parafield, Perth, Port Hedland, Rockhampton, Sunshine Coast, Sydney and Tamworth.



## Aviation communications, surveillance and navigation systems

We install and maintain hundreds of both ground and satellite based surveillance technology, landing aids and navigation beacons.



## Aviation Rescue Fire Fighting services at major airports

We are one of the world's largest aviation fire fighting organisations with around 850 operational and support personnel based at 27 of Australia's busiest airports. We provide Aviation Rescue Fire Fighting services at the following airports:

Adelaide, Alice Springs, Avalon, Ayers Rock, Ballina, Broome, Brisbane, Cairns, Canberra, Coffs Harbour, Darwin, Gladstone, Gold Coast, Hamilton Island, Hobart, Karratha, Launceston, Mackay, Melbourne, Newman, Perth, Port Hedland, Rockhampton, Sunshine Coast, Sydney, Townsville and Whitsunday Coast (Proserpine).



## Management of aircraft noise

We operate the national aircraft noise and flight path monitoring system and also manage all aircraft noise complaints through our Noise Complaints and Information Service.

## Fast facts

- We safely manage 11 per cent of the world's airspace including more than 150 million passenger movements across almost 4 million aircraft arrivals and departures annually.
- We employ around 1,000 air traffic controllers and 850 aviation rescue fire fighters, as well as technical officers and engineers.
- We maintain an asset base valued at more than \$1.8 billion at more than 700 locations across the country.
- Our activities are funded by airspace users, who use the vast range of services and facilities we provide.



# Air traffic control

Air traffic control manages the safe and orderly flow of aircraft into, out of and across Australian airspace.

Our air traffic controllers keep aircraft at safe distances from each other in the air and on the ground, while arranging them in an order for landing or take-off along organised flight paths.

We use systems and processes to allow the maximum number of aircraft to fly safely in our skies.

Air traffic control services at a military airports such as Darwin, Townsville and Williamtown are provided by the Royal Australian Air Force. Airservices' aviation rescue fire fighters may still have a role at these airports.

## Types of air traffic controllers


### There are three types of air traffic control

Tower controllers are located at an airport's control tower and are responsible for all aircraft and vehicle movements on taxiways, runways and in the immediate vicinity of the airport. Tower controllers separate aircraft visually but use a range of technology to assist with this.

Terminal or approach controllers use surveillance technology to manage the flow of aircraft arriving and departing from major city airports. Airservices provides air traffic control services in an extended area around capital city airports, and these controllers are instrumental in maximising the safe use of this busy airspace.

En route controllers located in Brisbane and Melbourne are responsible for all aircraft flying outside tower and terminal airspace. These controllers are responsible for the majority of air traffic over the Australian mainland and on oceanic routes within Australia's flight information region and on behalf of Nauru and Solomon Islands.

## Who's in control?



# How airspace works

Airspace is classified into 'categories' which determine the level of service provided. In Australia these range from Class A (typically en route, high level airspace), through to Class G (uncontrolled airspace predominantly used by light aircraft).

## Controlled vs uncontrolled airspace

Airspace is designated as 'controlled' or 'uncontrolled'. Controlled airspace in Australia is actively managed by air traffic controllers and is broken up into a number of different classes or classifications.

To enter controlled airspace, an aircraft must first gain a clearance from air traffic control. In contrast, no clearance (or supervision by air traffic control) is required to operate in uncontrolled airspace. The large majority of light aircraft operate outside or underneath controlled airspace (for example, aircraft that operate at low levels over Sydney Harbour).

The service provided by air traffic control varies depending on the class of airspace:

- Separation service: air traffic controllers keep aircraft a minimum distance apart to reduce the risk of collision and to reduce the impact of wake turbulence.
- Flight information service: the provision of advice and information which may be valuable for the safe and efficient conduct of flight.
- Traffic information service: information issued by controllers to alert the pilot of an aircraft that another aircraft may be close to their position or intended route.

The diagram on page 17 represents the classes of airspace in Australia and how they connect and overlap. The level of service an aircraft receives from air traffic control and the classes of airspace in which it can fly are determined by whether it is operating under visual flight rules (VFR) or instrument flight rules (IFR).

## Terminal airspace

Terminal airspace is the airspace surrounding a major airport, generally within a 30-50 nautical miles (55-90 kilometres) radius. In the case of some major airports, this airspace extends from ground level up to 28,000 ft (approximately 8,500 metres).

As the distance from the airport increases, the lower boundary of the control zone rises in steps (see diagram page 17), enabling other airspace users (such as gliders and balloons) to operate outside terminal airspace without requiring an air traffic clearance.

## Restricted airspace

In this airspace, aircraft movements are restricted in accordance with certain specified permissions. Examples of restricted airspace include airspace around military installations and high density flying operations at an air show or other large public event. Restricted airspace may be imposed by police for safety or security reasons in the vicinity of bushfires or major crime scenes. Decisions on restricted airspace are made by the Office of Airspace Regulation.

## No-fly zones

No-fly zones are similar to restricted airspace but are imposed and enforced by the military (usually the Royal Australian Air Force). No-fly zones will often be established around military exercises, heads of government meetings and major events such as the Olympic or Commonwealth Games. Airservices has no authority or control over no-fly zones.



### Legend

- Air traffic towers 29 locations
- ▲ Aviation rescue fire fighting stations 27 locations
- Air traffic services centres 4 locations

# Separation standards

Air traffic controllers apply separation standards to keep aircraft a minimum vertical or horizontal distance apart operating in controlled airspace and at airports.

When two aircraft experience a loss of the minimum separation distance (which varies depending on the airspace classification), it is referred to as a Loss of Separation (LOS). A LOS does not mean that the aircraft were at immediate risk of colliding or that the incident was a 'near miss', it simply means that separation standards were not maintained. Inadequate Separation Assurance is when separation exists however the conflict is not identified, or is unplanned, not executed appropriately, not monitored or inappropriately monitored.

Different separation standards apply depending on whether aircraft are operating under instrument flight rules (IFR—all large passenger aircraft) or visual flight rules (VFR—most light aircraft and helicopters).

## Vertical separation

In Australia, aircraft flying in controlled airspace up to 29,000 ft (8,800 metres) should not come closer than 1,000 ft (305 metres) vertically to another aircraft unless they are separated horizontally. Above 29,000 ft, the vertical separation increases to 2,000 ft (610 metres), except in airspace where Reduced Vertical Separation Minima is applied.

## Reduced Vertical Separation Minima (RVSM)

RVSM allows aircraft equipped with modern altimeters and autopilot systems and flying between 29,000 and 41,000 ft (8,800–12,400 metres) to be vertically separated by a minimum of 1,000 ft (305 metres) rather than the standard 2,000 ft (610 metres).

## Horizontal separation


In controlled en route airspace, the horizontal separation standard between aircraft flying at the same altitude is five nautical miles (9,260 metres). If aircraft are separated vertically, horizontal separation can be reduced. Horizontal separation prevents aircraft flying into another's wake turbulence. In terminal airspace, the minimum separation is three nautical miles (5,500 metres). Within the confines of an airport control zone, separation may be reduced providing the aircraft are sighted by the tower controller remain visually separated.

## How far is five nautical miles?

5 nm is 9.26 km or 9,260 m

- In Sydney 5 nm is the approximate distance from Sydney Airport terminal to Hyde Park (as the crow flies).
- In Melbourne, it is approximately Flinders St Station to Williamstown.
- In Brisbane, it is approximately Queen St Mall to Mount Gravatt.

In areas outside of surveillance coverage or other satellite-based navigation services, separation of aircraft is achieved by the application of various procedural rules, for example, based on time and their estimated position.



# Australian airspace architecture

There are two types of airspace— controlled and uncontrolled. Controlled airspace is broken down into a number of different classes. Depending on how far and how high an aircraft wants to fly, it will pass through different classes of airspace, in which different rules will apply to it.

**Class A**  
This high-level, en route controlled airspace is used predominantly by commercial and passenger jets. Only IFR flights are permitted and they require air traffic control clearance.

**Class C**  
This is the controlled airspace surrounding major airports. Both IFR and VFR flights are permitted and both require air traffic control clearance.

**Class D**  
This is the controlled airspace that surrounds general aviation and regional airports equipped with a control tower. All flights require air traffic control clearance.

**Class E**  
This mid-level en route controlled airspace is open to both IFR and VFR aircraft. IFR flights are required to communicate with air traffic control and must request a clearance.

**Class G**  
This airspace is uncontrolled. Both IFR and VFR aircraft are permitted and neither require air traffic control clearance.



Enroute controllers are located in two main centres, Melbourne and Brisbane, which manage airspace south and north of the white line respectively.

# Classes of airspace

The diagram below represents the classes of airspace in Australia and how they connect and overlap. The level of service an aircraft receives from air traffic control and the classes of airspace in which it can fly, are determined by whether it is operating under visual flight rules (VFR) or instrument flight rules (IFR).





### Visual Flight Rules (VFR)

The minimum vertical and horizontal separation in visual flight conditions can be less than instrument flight rules. At, or in the vicinity of an airport with a control tower, VFR aircraft may operate at the same level as other VFR aircraft as long as they are provided traffic on other VFR aircraft in the same area by ATC.

In the air, depending on the operations being performed, and where they are being performed, VFR aircraft may separate themselves. For example, over Sydney Harbour, sightseeing helicopters use the 'see and avoid' principles where VFR pilots maintain their own separation from each other.

For general aviation aircraft (non commercial aircraft), outside of controlled airspace, separation can be as close as 500 ft (152 metres) vertically and horizontally. Some aircraft (for example, during formation display flying) may operate closer with dispensations from the Civil Aviation Safety Authority.

### Flight paths

The term 'flight path' is used to refer to the corridor where the aircraft fly most of the time. Flight paths can be a number of kilometres wide. Over time, as navigation technology has improved, flight corridors have generally become narrower.

Factors such as aircraft type, weight and weather conditions can determine how precisely aircraft fly within corridors. From the ground, it can appear that aircraft that should be flying the 'same' path, are flying a different path. This leads to the perception that aircraft are flying on the 'wrong' or a 'new' flight path, which is rarely the case.

Aircraft may be required to deviate from the usual flight paths by air traffic controllers to ensure safe separation between aircraft, to avoid emergency firefighting, search and rescue, medical or police operations, or if an aircraft conducts a missed approach. Pilots may also ask to fly different routes to avoid bad weather and storm cells.

### How low can they go?

Aircraft can fly no lower than 1,000 feet (305 metres) above the ground in built-up areas or 500 feet (152 metres) in non-residential areas unless they are in the process of landing or taking off. Helicopters may fly below 1,000 feet in specified areas.

In some circumstances, a 'low flying permit' may be required, which is issued by the Civil Aviation Safety Authority. Additionally, pilots may be required to have a special 'low flying' endorsement attached to their pilots licence.

### Service disruptions

#### Equipment failure

Air traffic control services may sometimes be adversely affected by the failure of radar or other facilities or equipment. This can result in a reduction in the normal level of service, or a suspension of air traffic control in an area of airspace.

In these cases, back-up processes, procedures, and specific contingency plans are always available and activated as required.

#### What happens when normal ATS is temporarily not available?

When there is a temporary variation to air traffic services, a Notice to Airmen (NOTAM) is issued to let pilots know what services are still available, including assistance to either operate clear of the affected airspace, or to operate in the airspace safely under modified procedures. This information is reported by Airservices regularly and is available on our website [airservicesaustralia.com](http://airservicesaustralia.com)

# Our technology

Australia's aviation industry relies on Airservices for the provision and maintenance of air navigation technology and equipment critical to aviation safety at major and regional airports, aerodromes and airstrips.

## Surveillance

### Automatic Dependant Surveillance Broadcast (ADS-B)

ADS-B is satellite-based technology which requires aircraft to be fitted with an ADS-B capable transponder. Ground receiver stations comprise of an antenna that receives data transmitted from an aircraft's transponder via satellite providing accurate surveillance information. The aircraft's ADS-B data is then displayed on a controller's screen exactly the same as it would using radar.


### Radar

Airservices uses Terminal Area Radar (TAR) and en route radar to assist with separation of aircraft in controlled airspace. At major airports it is common to have both radars in use.

Known as primary radar, TAR relies on radio waves reflecting off metallic objects and is effective within a short range from the radar. Regardless of whether an aircraft has a transponder, primary radar (usually used in conjunction with a secondary surveillance radar) will detect an aircraft's position, height and approximate airspeed. TARs are useful for detecting aircraft in controlled airspace close to the airports.

En route radar, or secondary surveillance radar, relies on an aircraft having a transponder which transmits a data signal. The signal is received and interrogated by a ground station. En route radar covers larger volumes of airspace ranging from 250 nautical miles (463 kilometres) in radius and up to 100,000 ft. (30 kilometres).

### How ADS-B works



### Instrument Landing System (ILS)

An ILS is a highly accurate radio signal navigation aid used by pilots for landing at an airport when there is poor weather or low visibility.

An ILS consists of two antennas which transmit signals to receivers in the aircraft cockpit – a glide path tower located next to the runway, and a localiser installed at the end of the approaching runway. These antennas provide a pilot with vertical and horizontal guidance when landing.

### Advanced Surface Movement Guidance And Control System (A-SMGCS)

A-SMGCS works in a similar way to ADS-B but on the ground. Aircraft and ground vehicles are fitted with a transponder which transmits a signal to a receiver at the airport.

A-SMGCS is used at major airports and shows the position of aircraft and ground vehicles on a screen in front of the surface movement controller in the control tower.

### Ground Based Augmentation System (GBAS)

GBAS uses just one array of four short transmitters or receiver towers on an airport. GBAS can guide up to 26 simultaneous and highly precise aircraft approaches.

### Oceanic flight tracking

Flights in oceanic areas are unable to be tracked using traditional radar as this form of surveillance relies on ground-based sites.

We use satellite-based positioning technology to track all suitably equipped flights in oceanic airspace once every 14 minutes using satellite-based communications equipment called Automatic Dependent Surveillance Contract (ADS-C). Aircraft automatically report their exact position using ADS-C technology. The increase in reporting frequency allows air traffic controllers to track an aircraft's position and predict its next position with greater accuracy. This information also allows controllers to observe and react to any unusual flight behaviour and notify search and rescue agencies earlier if necessary.

### OneSKY Australia™ Program

OneSKY Australia™ is the most complex transformation of air traffic management in Australian aviation history. A partnership between Airservices and the Department of Defence, OneSKY Australia™ will replace Australia's separate civil and military air traffic management systems with a common, advanced and integrated system known as the Civil Military Air Traffic Management System (CMATS) to achieve national harmonisation in air traffic management.

Introducing a next-generation and secure-by-design system represents a significant capability uplift in national airspace management – enhancing Australia's safety, resilience, efficiency, national security, and military preparedness. OneSKY Australia™ is estimated to deliver more than \$1.2 billion of economic benefits to Australian airspace users over 20 years.

The new capability will meet future needs of contemporary defence operations and will contribute towards more efficient and environmentally-friendly civil flight operations. The scalable and feature-rich new system will also enable management of constantly growing and more complex air traffic.

# Aircraft noise

Managing aircraft noise in Australia is a shared responsibility between Airservices, airlines, aircraft operators, airports, federal government agencies and state and local governments. Airservices works with these partners to minimise the impacts of aircraft noise on communities where it is safe and practicable to do so. This includes:

- Designing departure and arrival flight paths that provide the best possible noise outcomes
- Engaging with industry and the community about proposals for new or changed flight paths
- Identifying and investigating opportunities to reduce noise
- Participating in Community Aviation Consultation Groups run by airports
- Providing information to the community about aircraft noise and airport operations.

## Aircraft Noise Ombudsman (ANO)

Airservices works with the independent office of the ANO to improve the way in which we respond to community concern about the impact of air traffic on communities. The ANO's website is [ano.gov.au](http://ano.gov.au)

## Noise abatement procedures

Every major airport has Noise Abatement Procedures which are designed to reduce the impact of aircraft noise on the community. These are implemented by air traffic control but their use is subject to weather conditions and aircraft requirements.

## Noise complaints

Airservices is responsible for responding to complaints in relation to aircraft noise through the dedicated Noise Complaints and Information Service. For more information see [airservicesaustralia.com/aircraftnoise](http://airservicesaustralia.com/aircraftnoise)



# Weather

Airspace and airports have a limited capacity, like highways and city roads. An added complexity is the significant impact weather can have on airspace and airport capacity. Low cloud, fog and rain may disrupt visibility at or around an airport, affecting aircraft operations.

Thunderstorms and lightning strikes will also see aircraft re-routed or diverted. Ground operations at airports may be stopped when thunderstorms are in the area to prevent injury from lightning strikes.

## Minimising disruptions

Airservices' National Operations Management Centre (NOMC) in Melbourne works closely with the Bureau of Meteorology, air traffic controllers nationally and our airline customers to minimise disruptions caused by weather. The NOMC will plan the movement capacity per hour of the major airports to match the operating conditions at each airport.

With the use of Ground Delay Programs (GDPs), aircraft are instructed to wait on the ground for their allocated departure slot. This is a bit like traffic lights on a highway ramp metering the flow of cars onto a busy road. Although weather may be fine at the departure airport, the departure delay is to manage the demand at the destination in line with the planned capacity. This prevents excessive airborne delays which would result in increased fuel burn and CO2 emissions.

## Flight cancellations

Sometimes the available capacity needs to be reduced due to prevailing weather or operational restrictions, prompting airlines to make the decision to cancel some of their flights. Flight cancellations are careful commercial and logistic considerations by airlines, outside of the control and influence of Airservices. Often airlines will try to combine flights on busy city pairs to get passengers to their destination with as little impact as possible.

## What impacts runway selection?

Weather, in particular wind speed and direction, is generally the main factor in determining which runways are in use at an airport, which direction aircraft will take off and land and which flight paths are used.

Aircraft need take off and land into the wind, or with minimal tail wind. As a result, the wind direction (both current and forecast) dictates the selection of runway/s in use at any time. This in turn determines which flight paths are used and this can change at short notice.

Wind blowing across the runway is called a cross wind. Aircraft can take off or land generally with only a low cross wind, usually up to a strength of about 15 knots (28 kilometres per hour). Above that strength of wind, an aircraft may have to use another runway or divert to an alternative airport.

## Windshear

Windshear is a sudden change in wind direction or speed and is usually associated with thunderstorm activity. Windshear can be either vertical or horizontal and can have a significant impact on the control of aircraft during take-off and landing.

## Volcanic ash

Airservices works closely with the Bureau of Meteorology's Volcanic Ash Advisory Centre to monitor volcanic ash in the Asia-Pacific region. Airservices does not close or restrict airspace as a result of volcanic ash but provides advice to airlines on the likelihood of encountering ash. Airlines will make individual decisions on whether or not to fly in or around ash-affected airspace or to suspend their operations.

# Accidents and emergencies

Airservices provides Aviation Rescue Fire Fighting (ARFF) services at 27 of Australia's airports. The service operates 90 of the largest fire fighting vehicles in Australia—the high visibility Mk8 ultra-large fire vehicle.

## In flight emergencies

Air traffic controllers provide information and assistance to pilots in the event of an in-flight emergency. As with normal operations, the pilot remains in command of his aircraft at all times and is responsible for determining the safest course of action, such as where and when to land.

ARFF services will be advised of in-flight emergencies, at the discretion of the pilot, and will take a range of actions depending on the nature of the emergency. This will range from moving to a state of readiness at the fire station to pre-positioning vehicles at the runway for rapid intervention.

An emergency is declared when an aircraft is experiencing problems and there is a reasonable certainty of a threat to the safety of the aircraft or its passengers, and where emergency assistance is required. Airservices aviation fire fighters will also be alerted.

When a pilot declares an emergency to air traffic control, they will alert the controller to the severity by broadcasting either 'mayday' or 'pan-pan'.

A 'mayday' call indicates an aircraft is in grave and imminent danger and requires immediate assistance.

A 'pan' call is used to describe a less urgent situation but the pilot still requires attention from air traffic control.

An aircraft with a declared emergency will be provided priority for landing. A priority landing in itself is not an 'emergency landing'.

## Accident response

Aviation rescue fire fighters are required to respond and arrive on scene within three minutes to any aircraft incident on the airport movement area. We are also required to respond to any aircraft incident within 1,000 metres of an airport. In this circumstance, they will take command as first responders and local emergency services will be called out to assist, if required.

At airports without a dedicated aviation fire rescue service, or where an accident occurs more than 1,000 metres from an airport perimeter, local emergency services will take the lead.

The ARFF service operates difficult terrain vehicles and vessels for response where a significant proportion of aircraft movements take place over water, swamp or other difficult terrain on, or in, the immediate vicinity (1,000 metres) of the airport. Difficult terrain includes coastal and estuarine waters, swamp, mangroves, mud flats, marsh/bog, dense woodland, salt pans and sand dunes.

Airservices has water rescue capability of approximately 20 boats at 12 airports where there is water within 1,000 metres of the end of the runway. Aviation rescue fire fighters regularly respond to a host of different incidents every day ranging from medical emergencies to fire alarms.

## Accident investigation

Investigation into the cause of an aircraft accident is the responsibility of the Australian Transport Safety Bureau (ATSB). Airservices works cooperatively with the ATSB during all investigations relating to our operations.

## Search and rescue

The Australian Maritime Safety Authority (AMSA) is responsible for search and rescue coordination. On receiving a distress signal or notification of an aircraft accident, AMSA's Joint Rescue Coordination Centre in Canberra will coordinate search and rescue efforts, generally with the assistance of local emergency services.

Airservices also advises AMSA when pilots fail to cancel their search and rescue time (SARTIME). Pilots lodge a SARTIME with Airservices based on the expected duration of their flight.

If a SARTIME expires without being cancelled by the pilot, Airservices attempts to contact the pilot. If the pilot cannot be reached within 15 minutes, the information is passed to AMSA for further investigation.

## Emergencies outside controlled airspace

While air traffic controllers play a key role in assisting aircraft in distress, many light aircraft operate outside of controlled airspace and radar coverage.

Airservices may not have information relating to these aircraft or be the first-response agency in the event of an accident.

# Unusual activity

Airservices regularly receives calls relating to what is perceived as 'irregular' aircraft activity or other activity at an airport. It can be difficult for passengers or those on the ground to have an accurate picture or understanding of an incident or activity. Examples of activity that the public may consider unusual or cause concern are listed here.

## Go-arounds or missed approaches

A go-around, or missed approach (also sometimes referred to as an aborted landing), is a safe and well-practised manoeuvre that sees an aircraft discontinue its approach to the runway for landing. This standard manoeuvre does not constitute any sort of emergency or threat to safety, but may cause passengers or witnesses to become anxious.

During a go-around, the pilot will apply full take off power to the engine(s), adopt a nose-up take-off attitude, retract the landing gear and flaps and climb into the sequence to circle around for another approach.

A go-around may be initiated by the pilot, or the pilot may be directed to go-around by an air traffic controller.

The causes are usually adverse weather conditions including strong winds experienced by the aircraft on final approach. Other causes include debris on the runway (for example, tyre fragments from the aircraft in front), an aircraft that has been slow to take off or an aircraft (or vehicle) that has not yet cleared the runway. In these circumstances, a go-around is the safest approach.

Pilots may also deliberately conduct a missed approach as part of training, although this is not usually done with passengers on board.

## Aborted take-off

Similar to a go-around or missed approach, an aborted take-off is a procedure which sees an aircraft discontinue the take-off. Usually, it will be a pilot's decision to abort a take-off. Causes may include an engine malfunction or a bird strike.

## Activity involving fire trucks

Aviation rescue fire fighters are routinely called upon to respond to a range of emergencies, including first aid and medical emergencies, around the airport precinct.

When an aviation fire truck responds to an emergency, it will leave the fire station with its red and blue flashing lights operating and occasionally its siren activated. Responding fire trucks may drive across runways and taxiways under control of the air traffic controller. The sight of a fire truck driving quickly at an airport does not mean there is a concern for aircraft safety.

## Smoke and flames at an airport

Airservices ARFF service regularly conduct training exercises around the country for aviation fire fighters which may involve the creation of large amounts of smoke and flames. There may also be an unusually high number of emergency vehicle movements.

The appearance of smoke and flames at an airport does not mean there has been an accident or that there is any concern. Airservices regularly receives calls relating to what is perceived as 'irregular' aircraft activity or other activity at an airport. It can be difficult for passengers or those on the ground to have an accurate picture or understanding of an incident or activity. Examples of activity that the public may consider unusual or cause concern are listed here.

## Circuit training

At major general aviation airports around the country including Archerfield (QLD), Bankstown (NSW), Moorabbin (VIC), Parafield (SA) and Jandakot (WA), flight training schools regularly conduct circuit training. Circuit training sees aircraft, usually small single engine propeller trainers, fly over the surrounding suburbs at a height of 1,000 ft (305 metres).

## Low level flights

Occasionally, aircraft and helicopters fly at low level for law enforcement, rescue and military operations as well as for aerobatic or air show displays. Low level flying requires the aircraft operator and pilot to have a special endorsement and permission from the Civil Aviation Safety Authority.

In some areas, helicopters are required to fly at low level while arriving and departing an airport, sometimes as low as 500 ft (152 metres). Low level flight procedures are also used to navigate around controlled airspace and can see aircraft fly at low altitude through special flight corridors no higher than 1000 ft (305 metres).

## Laser attacks

Shining a laser at an aircraft is a criminal offence. Airservices encourages anyone who witnesses the shining of a laser at an aircraft to contact police immediately. Airservices does not investigate reports of laser attacks, but will pass on information provided by pilots to police. Air traffic controllers will also broadcast a warning to other pilots in the area.

## Bird strikes

Striking a bird while an aircraft is travelling at speed can cause damage to the airframe or engines. Depending on the size of the bird and where on the aircraft it comes into contact, a pilot may declare an emergency or request a priority landing as a precaution (see page 24).

## Remotely Piloted Aircraft Systems (RPAS)

The use of commercially operated remotely piloted aircraft systems, commonly referred to as drones, require registration and certification and their use is regulated by CASA.

Recreational drones are exempt from these regulations but users are encouraged to comply with a set of 'common sense' guidelines to ensure they do not cause injury or collisions with aircraft.


Operators of a drone must keep it more than 30 metres from people, vehicles, boats and buildings. Drones can also not fly over crowds or higher than 120 metres (400 ft) and must stay away from aircraft. Drones must also remain more than 5.5 kilometres from aerodromes and be kept in line of sight at all times.

More information is available at [casa.gov.au/drones](https://casa.gov.au/drones)

## Calibration of equipment

Airservices is responsible for conducting regular flight calibration inspections on around 500 navigational aids nationwide. This involves a specially-equipped aircraft conducting numerous 'missed approaches' to test and calibrate equipment usually at low level.





Airservices Australia  
GPO Box 367  
Canberra City ACT 2601  
[airservicesaustralia.com](http://airservicesaustralia.com)

